

GV-PCR1352 Enrollment Reader



INTRODUCTION

GV-PCR1352 is a USB card reader designed to assist with Card or Fob enrollment to GV-ASManager. It reads the ID number of a detected card or fob, and simulates entering the ID number into GV-ASManager or any other software. The user can easily create user accounts on GV-ASManager by inserting 13.56 MHz cards or fobs into the GV-PCR1352 Enrollment Reader.

SPECIFICATIONS

System Requirements		
OS	32-bit	Windows 7 / 8 / 8.1 / 10
	64-bit	Windows 7 / 8 / 8.1 / 10 / Server 2012 / 2012 R2 / 2016
GV-ASManager Version		All versions
Operational		
Frequency		13.56 MHz
Max. Distance		2 cm
Read Time		200 ms
Read Interval		0.5 s
Environmental		
Operating Temperature		0 ~ 50°C (32 ~ 122°F)
Operating Humidity		0 ~ 90% RH (non-condensing)
Mechanical		
LED Indicator		1 LED (dual-color; power, enrollment)
Connector		USB
Dimensions		110 x 80 x 26 mm (4.3 x 3.1 x 1.02")
Cable Length		140 cm (55")
Weight		160 g (0.35 lb)
Others		
Certification		CE, FCC, RoHS

Note:

1. Drivers are not required for GV-PCR1251 / 1352s.
2. Specifications are subject to change without notice.

ACCESSORIES

GV-AS ID Card, Key Fob, Patrol Fob, Sticker	13.56 MHz cards, fobs and stickers are available.
---	---